


CZXT199.516



20				
19	GB93-87	Spring Washer 10	32	Zn Plated
18	GB93-87	Spring Washer 8	4	Zn Plated
17	GB97.1-85	Washer 10	4	Zn Plated
16	GB97.1-85	Washer 10	32	Zn Plated
15	GB97.1-85	Washer 8	100	SS
14	GB6170-86	Nut M10	32	Zn Plated
13	GB6170-86	Nut M8	4	Zn Plated
12	GB5783-86	Bolt M10X30	32	Zn Plated
11	GB5783-86	Bolt M8X16	4	Zn Plated
10	GB5783-86	Bolt M8X25	96	SS
9	CZXT912.003	Cell Numerals	1Set	
8	CZXT831.002	Inner Shield Plate	2	
7	CZXT833.005-2	Base	2	
6	CZXT651.120	Inter-tier Connector	42	Solid
5	CZXT651.147	Main Terminal Connector	2	Solid
4	CZXT651.140	Inter-row Connector	2	Solid
3	CZXT872.014	Outer Shield Plate	2	
2	CZXT658.000	Insulating Bracket	2	
1	CZXT321.056	GTS6-800L MODULE	8	
No.	Code	Parts Description	Qty.	Remarks

NOTES:

- 1) Refer to installation and operating instruction (fig.8) for Intermodule Assembly.
- 2) Refer to installation and operating instruction (fig.5) for the Assembly of the lower module and base.

CAD No.
 Previous Previous No.
 Previous No.
 Signature
 Date

Mark	Qty.	Change	Signature	Date
Designed by				
Checked by				
Approved by				

48V		CZXT199.516	
GTS6-800L MODEL		Grade Mark Weight Scale	
GENERAL ASSEMBLY		Sheet No: 1 of 1	
		GASTON BATTERY	